

BTX1 PRO S



POCKET GUIDE




Frequency: 2.4GHz - Max power: 100mW

ENGLISH

 **MIDLAND®**

On/Off

Control description



Power on



Press 3 seconds



Blinking



Musical sound alert

Power off



Press together
3 seconds




Blinking



Musical sound alert

Pairing

Pairing description



ATTENTION: to make pairings, you need to access Setup. If you press the key 2 for less than 7 seconds, the unit will turn on instead of entering Setup. In this case, repeat the procedure.

To enter Setup mode

Status: Power off



Press 7 seconds



Lights up

To exit Setup Mode Interrupt the Pairing

Status: Setup mode and during pairing



Press twice

Pairing

Pairing to a phone/GPS/TFT

Status: Setup mode



Press 3 seconds



Blinking



Select device on the phone



Steady 1 second,
pairing successful

Note: To pair another phone/GPS (in audio mono only) follow the same procedure but press **Vol-**.

Note: it is possible to pair only 1 intercom (Midland, OBi or another brand) to each button. A new pairing will overwrite the previous one.

Midland/OBi intercom pairing

Status: Setup mode



OBi intercom
(Midland, Carado, Uclear)

Press 3 seconds



Blinking

Follow the **intercom**
pairing procedure



Steady, (1 second)

Pairing successful

Note: to pair another OBi intercom, follow the same procedure but press another button.

Pairing to a different brand unit

Status: Setup mode



Press 3 seconds



Blinking

Follow the **phone**
pairing procedure




Steady (1 second)

Note: to pair a second intercom of another brand, follow the same procedure but press another button. .

Pairing

Pairing 4 units in conference


Status: Setup mode



Note: the Conference mode allows the simultaneous communication amongst units. All units must be paired in a "chain" configuration: the Backwards button of the first unit must be paired to the Forwards button of the second unit and so on. For a detailed description of the function watch the tutorial video.

Pairing reset

Status: Setup mode



Press together
3 seconds



Lights up



Steady led

For more info visit: <https://support.midlandeuropa.com/>

Select a product and:
Watch **tutorial video** - Download **software**

Midland World



Download Midland Connect from **App Store** or **Google Play**




Operating modes

- A. Intercom mode:** to talk to another unit.
- B. Phone mode:** phone calls or manage music.
- Note:** *Intercom and phone modes are possible only when the units are paired.*

To change the operating mode

Status: Power on



Press 3 seconds

INTERCOM MODE



PHONE MODE

Press 3 seconds
to change modes
or keep pressed to
scroll through them
quickly




Operating mode
status

A. Intercom mode

Control description

RIDER 1 RIDER 2 RIDER 3
Main



To open/close intercom manually

Status: Intercom mode



Press once



Sound alert



Blinking

SHORTCUT - Remind - Operating mode status:
Press Vol-/Vol+ at the same time.

Note: *if you have paired another unit, push buttons 1 or 3 to open/close the intercom*

Operating modes

A. Intercom mode

To open/close intercom using the voice

Status: All modes



Say "Hello"



Sound alert



Blinking



Mute for 40 sec.
intercom is closed



Sound alert

Note: the voice activation is possible only if the unit is paired to button 2.

Enabling/disabling Vox

Status: All modes



Press 7 seconds



Sound alert

Note: Vox can be activated/deactivated through the Midland Connect App.

To open/close Universal Intercom

Status: Intercom mode



Press once
opens/closes
Universal Intercom



Blinking



Sound alert

Note: to open/close the audio from a different brand unit, use the voice dial command (for some models you have to send the command twice)

Note: if you paired a Universal Intercom device to another button, use this key to open/close intercom.


SHORTCUT - To open the intercom while listening to/sharing music in phone mode: press button 2 twice.

Operating modes

A. Intercom mode

To enable/disable Conference

Status: All modes



Press 3 seconds at the same time, **enables/disables** Conference




Sound alert




Conference status

To open/close Conference

Status: Conference



Press once **opens/closes** Conference to the unit paired to **button 1**



Press once **opens** Conference to **all units paired**



Press once **opens/closes** Conference to unit paired to **button 3**

Note: In Conference mode, the units paired to Vol+/Vol- are temporarily disconnected.


Operating modes

B. Phone mode

Control descriptions

(Phone paired on Vol+)

- Make a call
- Answer a call
- End a call
- Reject a call
- Song forward



(Phone paired on Vol-)

- Make a call
- Answer a call
- End a call
- Reject a call
- Song backward

Play/pause

To make a call

Status: phone mode



Press once



Voice assistant
(Google assistant,
Siri)



Give instructions
to your assistant



Call starts

Answer/end a call



Press once or say
“Hello” to activate
the voice call (vox,
phone)

Reject a call



Press 3 seconds

Note: if your phone is paired to Vol-, press button 3

Operating modes


B. Phone mode

Music

Status: phone mode



Select music App



Press once
Play/Pause



Press once
Song forward



Press once
Song backward

Music share

Status: phone mode



While you are listening to music, press 3 seconds to **activate/interrupt** music sharing with passenger (Music Share)

SHORTCUT - Music Play/pause in Intercom mode: press twice button 2.